



Install and fit parts and sub-assemblies in shown order (Fig.1). Cut pipe (14) if necessary to suit your personal HEIGHT requirements. Critical dimensions of Shower Hoop are shown in Fig.2