



INSTALLATION DETAILS:

- Ç Unfasten Screw (1) and remove Protective Cup / Mounting Guide (2) - see Fig.1.
- Ç Install Diverter Stem Extension (3) and secure with Screw (1).
- Ç Screw Trim Sleeve (4) over the valve body and tighten by hand.
- Ç Install Trim Plate (5), position as shown and secure by tightening Set -Screw (5.1) using 5/64" Allen key (supplied).
- Ç Install Handle (7) with inserted Spacer (6).
- Ç Test the system. Turn on the water. Rotate the handle and stop in the position when the maximum flow thru the ceiling mount shower is discharging. Reinstall the handle with the Lever Handle (applicable for T4XRBIQ trim kit) to be facing up or Square Handle (applicable for T4XRBIQ trim kit) to be aligned to Trim Plate (5). Secure the handle by tightening Set-Screw (7.1) using 2.5 mm Allen key (supplied). Turn the water off.